



# World Class Cleaning Solutions

## Case Study

Contract Manufacturer of Medical Devices

### CUSTOMER DETAILS

- Parts Cleaned:** Small parts, pins etc. 10-12" in length
- Removing What Soil(s):** Light machining oils
- Substrates:** Titanium and Stainless Steel
- Why are Parts Degreased:** In process cleaning for next manufacturing step

### BRULIN IMPLEMENTED PROCESS

- Current Chemistry:** AquaVantage® 815 GD
- Equipment:** Multiple 40 khz ultrasonic units
- Concentration:** 5-7%
- Temperature:** 150°F (65.5°C)
- Rinse:** DI water 150°F (65.5°C)

### REASON BRULIN WON

Cleaner parts, no residue.

