

World Class Cleaning Solutions

CASE STUDY

Medical Tubing Manufacturer



Customer Details:

Parts Cleaned: Vascular and Non-Vascular Tubing

Specific Substrates: PTFE

Removing What Soil(s): Light silicone film from outer surface used as a process lubricant Why are parts degreased: Preparation for additional part processing, not a final clean

Customer's BHC Process:

Chemistry: AquaVantage® 815 GD

Concentration: 7-10%

Washer Type: Custom Inline ultrasonic bath line

Temperature: 149°F (65°C)

Customer Improvement Requested: Removal of silicone residue from outer surface.